



Panaromic View Monitor (PVM)

OWNERS MANUAL

Please read this manual for proper operation and keep it for future reference.



TABLE OF CONTENTS

<Panoramic View Monitor (PVM)>

Section	Title	Page
1.0	Statements & Declarations	
1.1	Safety Instructions	1
2.0	Getting Started	
2.1	Background / Introduction	2
2.2	Information	2
2.3	PVM Features	2
3.0	Operating <Panoramic View Monitor (PVM)>	
3.1	360° Rotation Shortly	3
3.2	Gear: Reverse Mode (R)	4
3.3	Gear: Parking / Neutral / Drive Mode (P/N/D)	5
3.4	Turn Signal Mode	7
3.5	MOD Mode	7
3.6	Car model color change	8
3.7	Blind spot	8
4.0	Troubleshooting (If Available)	
4.1	Simple Troubleshooting	10

Please read this manual for proper operation and keep it for future reference.



SECTION 1.0

Statements & Declarations

1.1 Safety Instructions

Warning

The panoramic view monitor plays a subsidiary device in order to help driver checking surroundings around the vehicle. Please be sure that before driving, the visual check vehicle surroundings with mirrors before ready to go is necessary. Please pay attention to the following notices and instructions when using the panoramic view monitor.

Cautions

- Drivers shall not depend on the panoramic view monitor only. There have some different tolerance from the image and the actual object.
- Be sure to check vehicle surroundings visually before driving.
- When use panoramic view monitor, not only focus on monitor, but please also use vehicle mirrors to check actual conditions
- The position of guide line displayed on the monitor may differ from actual condition. Please check surround actual condition.
- When the tire size changed, the guide line position displayed on the screen will also be different.

Notice

- Do not use high-pressurized water column to wash panoramic view monitor to avoid damage.
- The distances between the vehicle and objects may differ from the actual distance
- There are blind spots around the vehicle so will not be displayed in panoramic view monitor
- The light condition around each camera is different, so light displayed on the image may differ
- The image from four cameras are combined. The border of the four image clarity may decline which is normal
- The car display image may differ from actual car, purpose is to simulate car's surrounding



SECTION 2.0

Getting Started

2.1 Background / Introduction

Panoramic View Monitor (PVM) System has 4 cameras installed at front / rear and left / right side mirror of the car, where its 360-degree bird's eye view is displayed on the Display Audio for guidance of blind spot areas against the car.

2.2 Information

-

The screen illustrations used in this manual are examples, and may differ from the image of actual car displayed on unit.



2.3 PVM Features

- Assist blind spot area visibility by seamless image with front, back or left and right view.
- PVM guide line design, seizing distance between periphery obstacles and vehicle itself.
- Front/rear guideline refers to car width which design to assist low speed reversing or driving.
- Due to safety concerns, there will be a black mask area on top of the front view.
- When speed is over 20 ± 5 km/h, the PVM will deactivate and enter in AVX mode.
- Motion object detection mode activated when speed is around 0 km/h.
- Turn signal mode actived when user turn on LH/RH signal below 20 ± 5 km/h



SECTION 3.0


Operating <Panoramic View Monitor (PVM)>

1. Press  Apps icon to enter Apps mode.
2. Then, press  PVM icon to enter PVM mode.



3.1 360° Rotation Shortly

When press PVM icon to enter PVM mode, car model will display 360° rotation shortly and it is able to skip 360° preview by one-click.






SECTION 3.0

Operating <Panoramic View Monitor (PVM)>




3.2 Gear: Reverse Mode (R)

When Reverse Gear is engaged, the Display Audio will display panoramic image specified for reversing mode in 2-3 seconds automatically (please refer to the image below).





No	Display	Function
1	Vehicle width guide line	The width of guide line is wider than the vehicle width.
2	Distance guide line	The distance around 6.5 ft (2m) from the edge of the bumper.
3	Distance guide line	The distance around 3 ft (1m) from the edge of the bumper.
4	Distance guide line	The distance around 1.5 ft (0.5m) from the edge of the bumper.
5	Vehicle center guide line	The center of the vehicle.
6	Distance guide line	The distance around 3 ft (1m) from the edge of the bumper.

- The image show surrounding bird view and rear view to assist driver.
- Please be aware the distance with periphery obstacle.
- The panoramic image is a simulated aerial view. When the obstacle is close to the car, please stop the car and confirm actual secure distance before you go

In Reverse mode, you may press the view switch to choose rear view  or 360° view + rear view  or 360° view + rear top view 

360° view + rear view






SECTION 3.0

Operating <Panoramic View Monitor (PVM)>


3.3 Gear: Parking / Neutral / Drive Mode (P/N/D)

The car will keep displaying the PVM-ahead image mode if the shift lever at P/N/D and the speed under 20 ± 5 km/h.




- Due to safety concerns, the front view will not show the whole image. There will be a black mask area on top of the front view.
- The front guide line has blue lines. Please pay more attention to the distance with periphery obstacles when you drive. The front guide line 1 is about 3 ft. (1m) from the edge of the bumper.
- When you reverse, please use left/right side mirror to check surrounding area. Press icons to switch to different view.

360° view + front top view



360° view + front right view







SECTION 3.0

Operating <Panoramic View Monitor (PVM)>


Front view



360° view + rear right view




360° view + rear left view



Rear view



360° view + front left view






SECTION 3.0

Operating <Panoramic View Monitor (PVM)>


3.4 Turn Signal Mode

When the driver turn the left or right signal on and the speed is under 20 ± 5 km/h, The side view will be triggered.

360° view + 3D RH side view




360° view + 3D LH side view




3.5 MOD Mode

The PVM detects moving object and shows the direction of object coming from with yellow alarm.

Please be noted that the MOD is available only when the speed is around 0 km/h.




User can press MOD icon  to activate and close MOD function.




SECTION 3.0

Operating <Panoramic View Monitor (PVM)>


3.6 Car model color change

In P/N/D/R mode, press  “color change icon” can switch color of car model.



3.7 Blind spot

The aerial panoramic image comes from the use of optical principle, where intersection parts of four cameras are for image clipping process to build panoramic effect, hence, four connection parts of images listed below would cause image to temporarily disappear and drivers are requested to pay special attention.





SECTION 3.0

Operating <Panoramic View Monitor (PVM)>

Objects may not be detected from some angles. The objects underneath the bumper or on the ground may not be detected when they are displayed at front or rear viewing angle (Grey parts in oblique lines).

- The images from four cameras are in color difference under verified light source due to light incoming angle discrepancies, which is normal.
- The guide lines in the front left/right side of car mode are aligned due to shooting position/angle difference from left/right rear mirrors; however, mild staggered position of doors is normal.
- PVM display area is constricted, where the further part from the car body will present image deformation, which is normal.
- PVM camera are precision device. Do not hit camera, which might cause abnormal situations like failure or damage
- PVM is to aid and reinforce display of periphery blind areas against the car body. When you drive, you still must make use of the left/right side mirrors and rear view mirrors.
- When you reverse, some conditions (Ex.: weather, light) might constrict image. Do not drive your car only by the display.
- PVM image might be affected or incorrect with the change of tire size; hence, we do not suggest you to change tire size.
- Heavy impact or displacement from collision might cause PVM image to diverge right or left, worsening image connection. To resume normal operations, image calibration and part replacement may be required.



TOYOTA
ALL ABOUT THE DRIVE

SECTION 4.0

Troubleshooting

4.1 Simple Troubleshooting

Symptom	Likely cause	Solution
Difficult to see the image	<ul style="list-style-type: none"> • The vehicle is in a dark area. • The temperature around the lens is either high or low. • The outside temperature is low. 	Please move car away from the uneven light or direct sunlight.
	<ul style="list-style-type: none"> • There are water droplets on the camera. • The surroundings is raining or humid. 	Please move the car to the room temperature.
	<ul style="list-style-type: none"> • External factor (mud etc.) is adhering to the camera. • Sunlight or headlights is shining directly into the camera. • The vehicle is under fluorescent lights, sodium lights, and mercury lights etc. 	Please clean the camera with water and soft cloth.
The image is blurry	Dirt or external factors (like water droplets, snow, and mud etc.) attached to the camera.	Clean the camera with water and soft cloth.
The image is out of alignment	The camera or surrounding area got a strong impact.	Please have your dealer to check the vehicle
The guide lines are out of alignment	The camera position is out of alignment.	Please have your dealer to check the vehicle.
	<ul style="list-style-type: none"> • The vehicle is tilted. (Heavy load, tire puncture, etc.) • The vehicle is in a slope status. 	This is not malfunction. Please check surroundings visually when reversing the car.